



Contractor must use tapcon screws to adhere girts to CMU block and stainless steel tapcon screws to adhere girts to CMU block on treated lumber.

Contractor must coordinate with MoDOT to relocate small shed on right elevation side of building. Will be relocated by MoDOT.

MoDOT will pull out propane line from CMU blocks.

Contractor to provide and install additional downspout in middle of rear elevation.

Contractor to provide concrete splash block for each downspout on rear elevation. Total of 3 splash blocks.

Contractor must install metal siding to the lowest mortar joint at grade.